


















FR Instructions de montage  
EN Assembly Instruction  
ES Instrucciones de montaje  
PT Instruções de montagem  
DE Aufbauanleitung




Prod. Code : 879772 & 879825 & 879826 & 879827 & 879828 & 879829 & 879830 & 879852 &  
879856 & 879857 & 879858 & 951263 & 952994 & 953014 & 953038

A	1		K	1	
B	1		L	1	 (M6X15)
C	1		M	1	
D	4	 (M10X25)	N	1	 (S5)
E	4	 (M10X20)	O	1	 (S8)
F	8	 (Φ10 )			
G	1				
H	1				
I	1				
J	1				


01:




02:




03:




04:




05:




06:




07:




08:




09:




10:




11:



12:



01:



02:

