




Bedienungsanleitung / Manual



WICHTIG - IMPORTANT

Vor Gebrauch sorgfältig lesen! Für späteres Nachschlagen aufbewahren!

Carefully read before use! Keep for looking up later!



Art. Nr:30233849 Vers.: 1.0

Allgemeine Hinweise:

ACHTUNG: Der Wagen ist konzipiert für den Freizeitgebrauch z.B zum Transport von Picknick –und Campingausrüstung und ist NICHT geeignet zum Transport von Kindern. Das kann lebensbedrohlich sein.

Beim Überfahren von hohen Hindernissen wie Bordsteinen/kanten mit dem Wagen ist Vorsicht geboten und für den Einsatz auf unebenem Gelände ist dieser weniger geeignet.

Für entstandene Schäden durch unsachgemäßen Gebrauch übernimmt die BAHAG AG keine Haftung.

General information:

ATTENTION: The wagon is made for recreational e.g. for the use to transport picnic and camping equipment and is NOT suitable for transporting children. This can be life-threatening.

Caution should be exercised when driving the wagon over high obstacles such as curbs and it is less suitable for the use on uneven terrain.

BAHAG AG assumes no liability for damages caused by improper use.

