












LED S-C4

30-5377-81-81









8








9






①	LIGHT ON/OFF
②	FAN ON/OFF
③	4
④	3
⑤	2
⑥	F/R
⑦	5
⑧	1
⑨	1H
⑩	8H
⑪	4H








5






NO

6



NO





7




OK

8

OK



ON



OK