


AP BOX INSTALLATION




1. Remove the upper part and visualize the 4-pin connector that is located as shown in photo.




1. Place the AP BOX as shown in the photo, on top of the black cooling plate, using the double-sided adhesive tape. Make sure to place it on top with label facing upwards.

AP BOX INSTALLATION



3. Connect AP BOX to the 4-pin connector and make sure to place the cable inside before closing the upper cover.



4. In the smallest model, 2.6hp long and short shaft, there may be little space. We suggest to place the AP box as shown in photo.