






15 min



AUFBAUANLEITUNG




SCHRITT I




SCHRITT II

A-x2



B-x4




C-x1




TEILELISTE


①		6 x 35mm	4X
②		6 x 15mm	4X
③		6 x 30mm	1X
④		6 x 20mm	16X
⑤			8X
⑥		6x10x1mm	8X
⑦		6x13x2mm	8X
⑧		M4	2X
⑨			1X



SCHRITT III



SCHRITT IV



SCHRITT V

OSBY DININGTISCH D: 120 CM SUNFUN

Art.: 31311508

Length: 120 cm N.W.: 36 kg

Width: 120 cm G.W.: 42,5 kg

Height: 76 cm

BAHAG AG
Gutenbergstr. 21
68167 Mannheim
Germany

service@bauhaus.info



VNM Made