






Bitte prüfen Sie Ihre vorhandene Einbausituation. Messen Sie von der Wandfliese bis zum äußeren Wannenanrand

Check your current installation setup. Measure from the wall tile to the outer edge.



| A         | B    |
|-----------|------|
| 70 - 73   | 59,3 |
| 73 - 76   | 62,3 |
| 76 - 79   | 65,3 |
| 79 - 82   | 68,3 |
| 82 - 85   | 71,3 |
| 85 - 88   | 74,3 |
| 88 - 91   | 77,3 |
| 91 - 94   | 80,3 |
| 94 - 97   | 83,3 |
| 97 - 100  | 86,3 |
| 100 - 103 | 89,3 |



PDF ↓