



Cordless Leaf Blower

GE-CL 18/1 Li E-Solo

Item No.: 3433541 Ident No.: 21010

Bar Code: 4006825651645

The GE-CL 18/1 Li E-Solo cordless universal blower is ideal for blowing leaves, grass clippings and other dirt and debris from courtyards, driveways, footpaths, garages, terraces and outdoor furniture. The handy size and low weight enable very user-friendly operation. The split tube allows for easy cleaning of outdoor furniture in confined spaces while the full-length tube makes quick work of paths and driveways. Thanks to the detachable tube the storage of the blower is also space-saving. Additionally the electronic speed control allows the user to vary the air speed to suit the application while the soft grip handle provides added comfort during use.

This product comes without a battery and without charger which are available separately.

Features & Benefits

- Low weight and easy handling
- 2-parts tube fur universal operation around house and garden
- Electronic speed control
- Softgrip for user-friendly operation
- Strong blow velocity with 210 km/h
- Supplied without battery and charger (available separately)

Technical Data

 No-load speed (idle speed) 	
- Max. air volume	


- Blow velocity

12000 min^-1 105 m³/h 210 km/h

Logistic Data

- Product weight
- Gross weight single packaging
- Dimensions single packaging
- Pieces per export carton
- Gross weight export carton
- Dimensions export carton
- Container quantity (20"/40"/40"HC)

1.33 kg 1.91 kg 490 x 155 x 182 mm











Available as special accessories



18V 30min Power X-Change Charger Item No.: 4512011 Bar Code: 4006825587029 Einhell Accessory

Power-X-Twincharger 3 A



Charger Item No.: 4512069 Bar Code: 4006825629729 **Einhell Accessory**

18V 3,0 Ah PXC Plus Battery Item No.: 4511501 Bar Code: 4006825644197 **Einhell Accessory**



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097 Bar Code: 4006825646962 **Einhell Accessory**



18V 2,0 Ah Power-X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory

18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698 Einhell Accessory



2,5 Ah Power X-Change Battery Battery Item No.: 4511516 Bar Code: 4006825650518 **Einhell Accessory**













Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory 18V 4,0Ah PXC Starter Kit

18V 4,0 Ah Power-X-Change

Battery

PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory

Battery-Running-Times

running time (in min.)

Used Mode	Min. electronic speed	
Usage	blowing	
Unit of measure	min.	
with 1.5 Ah PXC	180	
with 2 Ah PXC	240	
with 2.5 Ah PXC	300	
with 2.6 Ah PXC+	330	
with 3 Ah PXC	390	
with 3.0 Ah PXC+	390	
with 4 Ah PXC	480	
with 5.2 Ah PXC+	660	
with 4-6 Ah PXC+ (4 Ah mode)	480	
with 4-6 Ah PXC+ (6 Ah mode)	720	
best performance with min.	all packs	



Power-X-Boostcharger 6 A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory

2x 3,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512083 Bar Code: 4006825638509 **Einhell Accessory**



2x 3,0Ah & 30min PXC Kit PXC-Starter-Kit Item No.: 4512098 Bar Code: 4006825646986 Einhell Accessory



running time (in min.)

Used Mode	Max. electronic speed	
Usage	blowing	
Unit of measure	min.	
with 1.5 Ah PXC	10	
with 2 Ah PXC	14	
with 2.5 Ah PXC	16	
with 2.6 Ah PXC+	17	
with 3 Ah PXC	20	
with 3.0 Ah PXC+	20	
with 4 Ah PXC	26	
with 5.2 Ah PXC+	40	
with 4-6 Ah PXC+ (4 Ah mode)	26	
with 4-6 Ah PXC+ (6 Ah mode)	42	